



User Manual for
MacWireless WiFinder

Table of Contents	
Introduction	1
Installation	1
Battery Replacement	1



Introduction

Thank you for purchasing a MacWireless WiFinder. Please see below for instructions on how to set up and use your device.

Installation

The MacWireless WiFinder is a click-and-go device.

1. Point the arrow at the end of the WiFinder in any direction.
2. Click and hold the WiFinder button. The LEDs will scan back and forth until the WiFinder finds a signal.
3. When the LEDs stop scanning back and forth and the WiFinder has found a signal, the LEDs will display the signal strength using a scale of one (weak) to four (strong) LEDs.
4. Continue to hold the button down and point the WiFinder in different directions to find where the signal is stronger. This process can be repeated until the source of the wireless signal has been found.

Please note that if the WiFinder does not stop scanning, then you have not found a signal yet – keep searching until you find one.

Battery Replacement

Remove the three screws from the back of the WiFinder and gently open the case. Remove the batteries and insert two new CR2032 batteries with the positive (+) side up. Put the case cover back on and replace the screws.

Disclaimer: Although this product has been tested and verified, MacWireless does not accept responsibility for loss or damage to any equipment or device. Use at your own risk.